



33 Ramland Road South
Orangeburg, NY 10962

t: 845.365.1100 800.223.5466
f: 845.365.1285 www.arc-com.com

Cleaning Instructions: Komichi

Wash Cycle:

Process as ordinary colored fabric, temperature not to exceed 160°F. **Use synthetic detergent.** Add fabric softener to the last rinse.

Extracting Cycle:

Fabric requires no more than 2-4 minutes extracting, depending on the size of the load and equipment used.

Drying Cycle:

Do no overload dryer. Tumble dry 3-5 minutes on synthetic cycle (110°F). As with all polyester fabrics, excessive heat will detract from the permanent press characteristics of this fabric.

Finishing:

If the fabric is folded upon completion of drying cycle, no finishing is required. Occasional light touch-up with hand iron (275°F maximum), or Flat Bed Press with covered head may be desired for smoother seams. **Use cover cloth between fabric and iron or pressing head. Avoid prolonged contact with head.**

Always process one single cubicle first before processing bulk cubicles. A thorough examination & evaluation of the test cubicle should be reviewed to make sure that the proper results are attained.

Do not use caustic soap or bleach.
Do not put through mangle.